

# **GT-2000 SERIES**

# MULTIFUNCTIONAL GAS ANALYZER





## Contents

1. Warranty 3
2. Product Brief Introduction 3
3. Product Features 4
4. Product Structure 5/6
5. Technical Parameters7
6. Detector instructions 8
6.1.Button Definition8
6.2.Charging mode 8
6.3.Parameter modification 8
6.4.Shortcut descriptione9
7. Operation instructions9
7.1.Operation Interface9
7.2.Function Menu Instruction10
7.2.1: Basic Setting10/11
7.2.2: History Data Log12
7.2.3: Real-time Curve13
7.2.4: Zero Calibration13
7.2.5: Target Calibration14
(Do Not Calibrate Unless You Are Professional)14
7.2.6: Alarm setting14
7.2.7: Measure Mode15
7.2.8: Store Setting15
7.2.9: Print Setting16
7.2.10: Time Setting16
7.2.11: Factory Setting16
8. Common faults and solutions17/18
9. History data export instructions18
10. After-sales Service18
11. Common gas type list19



#### 1. Warranty

- Please read the user manual before using the gas detector controller.
- It is forbidden to disassemble the controller, repair and replace the spare parts without authorization.



- Installation, commissioning, setting and other operations must be carried out by professionals.
- The calibration should be carried out regularly, to replace the out-service gas sensors and broken sensors in time.
- Forbidden to use the sensor for over-range detection.
- Prevent the controller from falling from high or subjected to severe vibration and impact.
- Avoid to put the detectors under high temperature, humidity, dust particle environment.
- Replacing the battery needs to use the same type of battery and be carried out in a safe place.
- The charging must be carried out in a safe place, and use the special charger (DC12V/≥1A) equipped with this machine
- Don't block the gas inlet or gas outlet during use to prevent damage to the pump.
- Before entering the dangerous area, the human body shall release static electricity first, and then carry the instruments into the site.
- If the user manual is modified, please understand.

#### 2. Product Brief Introduction

GT-2000 multifunctional gas analyzer is a portable gas analyzer which can be configured flexibly up to 12 gas sensors or 8 gas sensors+1 dust sensor. With import gas sensors and advanced nanometer semiconductor technology, GT-2000 multifunctional gas analyzer can detect corresponding gas concentrations at the same time rapidly and precisely. Users can custom setting the parameters to ensure the operations are user-friendly. 7.4V 4000mA built-in high capacity polymer rechargeable battery to ensure a long standby time. The technical indicators, gas concentrations and history data can be display in the 3.5 inches IPS technical grade screen, Users can save concentration data, print and export data. Temperature and humidity sensor can be optional.





#### 3. Product Features

- With advance nanometer semiconductor technology, ultra-low power 32bit microprocessor, 24bit ADC data acquisition chip, outstanding accuracy clearly.
- 3.5 inches IPS technical grade display with a pixel up to 320\*480, display technical indicators and gas concentration value.
- Three concentration units are available PPM, %VOL, mg/m3.
- User can combine different sensor, 1-12 kinds of gas can be detect at the same time, temperature and humidity sensor and other kinds of sensors are available.
- Up to 369,600 groups data can be stored, user can view history data on the display or export the data to computer via excel formal.
- With temperature and humidity detection, user can detect temperature and humidity value
- Five operation modes are optional: Detection mode, Storage mode, Display mode,
   Printing mode, Pumping mode.
- With powerful pump allowing device working under tiny negative pressure condition, the reasonable gas chamber design ensures that the sensor is not affected by the pressure.
- With over-voltage protection, overcharge protection, electrostatic prevention, magnetic-field interference prevention
- ♦ All software automatic calibration, sensor up to 6 levels target calibration, ensure the accuracy and linearity of the entire measurement, also with data recovery function.
- Chinese and English operation model are available, user-friendly.
- With temperature and humidity compensating function. With dust filter and dust-proof design allow device applies in all sorts of harsh conditions. (Except the detector with dust detection function)



#### 4. Product Structure





**Note:** The GT-2000 series detectors are customizable products, please confirm the function with the sales.



#### 5. Technical Parameters

Product type:	Multifunctional gas analy	zer(Customize accord	ing to user's need)
Scalable gas sensor:	User can customize 1-12 parameters	gas sensors, please ref	er to the sensor
Temperature and humidity:	Temperature detection ran Humidity detection range	e	
Detection pattern:	Pumping, with built-in hi tiny negative pressure con		device working under
Indication accuracy:	≤±3%F.S	Linearity error:	≤±2%F.S
Response Time:	≤30 S (T90)	Zero drift:	≤±2%
Recovery Time:	≤30 S	Repeatability:	≤±2%F.S
Detection Mode:	Real-time detection mode freely	and timing detection	mode can be switch
Storage pattern:	Automatically saving and groups data, user can view	, ,	· 1 ·
Explosion proof sign:	Ex ia IIC T4 Ga	Shell material:	Aluminum
IP rating:	IP65	Operating temperature:	-30 ~ 50°C
Power Supply:	7.4V/ 4000mA high capacity polymer rechargeable battery	Operating humidity:	≤90%RH, Non-condensing
Dimensions and Weight:	Approx. 230*130*260 mm (L×W×H) Approx. 3.0 Kg (net weight)	Working pressure:	-30Kpa $\sim$ 100Kpa
Accessories:	Case, User manual, Certin handle, 0.8M hose	fication, 12V DC Char	ger, USB cable, Sample



#### 6. Detector instructions

#### 6.1. Button Definition

Button Name	Icon	parameter setting
Back	Back	Cancel/Return to previous menu
Up		Move up/ Move left
Down	$\bigcirc$	Move down/ Move right
OK/Menu	ОК	Enter menu(press and hold for 5 seconds)/ Confirm
Run/ stop	RUN STOP	Pump switch/ Manually store(long press)
Print	Print	Print data( micro printer is optional)
Save	Save	Manually store
Power	Power	<ol> <li>On/Off(press and hold for 5 seconds)</li> <li>Short press-Screen dim out</li> </ol>
Mute	Alarm 🔶 Mute 🌽	Under detection interface, Press " Back", "OK", "▲", "▼" button, Switch Alarm and Mute(Boot default mute)



#### 6.2. Charging mode

\*When low battery, use the matching charger (12VDC/≥1A) to charge.

\*The indicator light flashes blue during charging, and flashes green when charging is complete.

\*Please don't wait until the battery is fully used up before charging.

#### 6.3. Parameter modification

User can modify all parameters by "Back", "Up", "Down", "Ok" buttons. Move the cursor to modify the parameters.

#### 6.4. Shortcut description

\*Mute: When detector is in the state of alarming user can mute the detector by pressing the "Back",

"Up" or "Down" or "OK" button.

**\*Save manually:** When storage mode was preset as manually, user can save the gas concentration value of each channel by press the "Save" button in detection interface

\*Screen lock function: Short press the "Power" button, can dim out the screen, press again, the screen light up. The detector will dim out if not operated after 300 seconds.

#### Notice:


1. GT-2000 series multifunctional gas and dust detector could be work normally only in condition of the pump was switched on. Buttons only can be operated when screen light up.

2. GT- 2000 Dust Particle Counter doesn't has the "Pump Switch" function.



#### 7. Operation instructions

#### 7.1 Operation Interface



Long press the "Power" button, the screen will light up and display the sensor information. It needs about 1 minutes to warm up the gas detector. After power on, the screen will display the configured gas/ gases.



#### 7.2 Function Menu Instruction

Long press" OK" button for 5 seconds to enter function menu as shown in figure 10. Eleven sub-menus are including in function menu:Basic setting, History Log, RealTime Curve, Zero calibration, Target calibration, Alarm setting, Measure Mode, Storage setting, Print Setting, Time Setting, Factory Setting.In main menu move the cursor to different sub-menu by press "Up" and "Down" button,press "Ok" to enter corresponding sub-menu,press "Back" to return to normal detection interface or previous menu.

Main Menu 10	Basic Setting 11
🔅 Basic Setting	🗙 Sensor Setting
2 Realtime Curve	Channel Setting
History Log	Temp Correction
-Q: Zero Calibration	💪 Humi Correction
Target Calibration	Language Setting
(w) Alarm Setting	
🖹 Measure Mode	

#### 7.2.1 Basic Setting

In Basic setting menu user can see various setting as shown in figure 11,press "Up" and "Down" button to move the cursor , press "Ok" to enter sub-menu and modify parameters.

1. Sensor setting:(as shown in figure 12)User set detection range and units( ppm, mg/m<sup>3</sup>, mg/L, %VOL)of different gas

2. Channel setting: In this menu user can set to activate/shield one or various gas channels as shown in figure 13, and also allow user to check channel address.

3. Temp Correction: In this menu user were allow to modify the temperature parameter manually as shown in figure 14.

4. Humi Correction: In this menu user were allow to modify the humidity parameter manually as shown in figure 15.

5. Language Setting: User can switch between Chinese and English menu as shown in figure 16.

6. There have 2 Special Sub-menu: VOC Gas Name Setting and PM2.5 Sensor Setting.

These two sub-menu only will exist when the detector is equipped with VOC sensor and dust particle sensor. The user can choose the specific VOC gas name as shown in figure18, and choose the detection unit or the min detect diameter of dust particle(optional sensors).



	Sensor Setting	12	(	Channel Setting	13	Temp Correction 14
Sensor	Range	12	Sensor	Range	10	14
EX	0.01	PPM	EX	1	Open	Unit : Degree Centigrade
HCL	100.00	PPM	HCL	2	Open	Current Temp : 25.6
CH2O	50.00	PPM	CH2O	3	Open	
HCN	100.00	PPM	HCN	4	Open	Correct Para : 0.0
SO2	2000	PPM	SO2	5	Open	Show Temp : 25.6
HBr	10.00	PPM	HBr	6	Open	



#### 7.2.2 History Data Log

User can check history log, view history log curve, export history log and clear history log as shown in figure 17.

1. Check History Log:Press "OK" to enter this sub-menu, the sensor name, quantity of history data will be shown, press "OK" again to check all previous concentration datalogs as it shown in figures 18.

2. History Log Curve: 'Press "OK" to check history log in curve format as it shown in figures 19.

3.History Log Export:Press "OK" and follow the procedure as it shown in figure 20 to export the history data.

4.Clear CH History Log:Press "OK" to enter this sub-menu,in this menu users can view all the sensors and corresponding data quantity,press "OK" again to history data of specific channel as it shown in figure 20-21.5.Clear ALL History Log:Press "OK" to delete all history data.

\*Please make sure that you want to clear all data. If it is cleared by mistake, the data cannot be retrieved



	History Data Log	17
•	Check History Log	
0	History Log Curve	
0	History Log Export	
0	Clear CH History Log	
0	Clear All History Log	

Sensor	History Log Curve Channel	19
EX	1	Check
HCL	2	Check
CH2O	3	Check
HCN	4	Check
SO2	5	Check
HBr	6	Check

	Clear History Log	20
Sensor	Quantity	- 20
EX	124	Clear
HCL	124	Clear
CH2O	124	Clear
HCN	124	Clear
SO2	124	Clear
HBr	124	Clear

	History Log	18
Sensor	Quantity	10
EX	124	Check
HCL	124	Check
CH2O	124	Check
HCN	124	Check
SO2	124	Check
HBr	124	Check

1.Connect PC with USB	
2.Open The PC APP And Export	

	Clear His	tory Log	21
Snesor	Qua	ntity	_ 21
EX	124		Clear
н	Clear l	.og ?	lear
СН	Back	OK	lear
HCN	12	24	Clear
SO2	124		Clear
HBr	12	24	Clear

#### 7.2.3 Real-time Curve

In this menu users can view all the sensors and corresponding channel.Press "Enter" to check each sensor's real-time curve as shown in figure 22-23.

	Realtime Curve	22
Sensor	Channel	22
EX	1	Enter
HCL	2	Enter
CH2O	3	Enter
HCN	4	Enter
SO2	5	Enter
HBr	6	Enter





#### 7.2.4 Zero Calibration

If zero drift of the sensor is over range, user can proceed zero calibration ,the gas concentration are defaulted set to zero after zero calibration as shown in figures 24-25.

	Zero Calibration	24
Sensor	CENC	21
EX	0.00	Cali
HCL	0.00	Cali
CH2O	0.00	Cali
HCN	0.00	Cali
SO2	0	Cali
HBr	0.00	Cali

Zero Calibration		25	
Sensor		CENC	
EX		0.00	Cali
F	Calibrate ?		Cali
CI	Back	ОК	Cali
HCN	0.00		Cali
SO2	0		Cali
HBr	0.00		Cali

#### Special Note:

Zero calibration must be proceed in fresh air or high-purity inert gas(for example 99.999%VOL N2 etc)
 Do not operate zero calibration for those gases which already exist in the air, such as oxygen, carbon dioxide, nitrogen, dust particle.

3. When GT-2000 series gas detector combined with gas sensors, or with dust sensors, the detector has two calibration functions.

4. When GT-2000 series gas detector combined with dust sensor, the dust sensor doesn't has calibration functions.

Zero calibration must be proceed in a clean,dust-free space. Target calibration must be proceed in a professional dust calibration system.

#### 7.2.5 Target Calibration (Do Not Calibrate Unless You Are Professional)

Find a fresh-air environment. This is an environment free of toxic or combustible gases and a normal oxygen content(20.9%VOL); Dust detector need proceed in a professional dust detection system.

GT-2000 series gas detector provide 6 levels target gas concentration calibration, as shown in figure 26-27, this calibration should be operate under conditions of certain standard concentration gas, Pressure reduction valve ,Flow meter, Calibration cover and make sure all instruments are well connected, otherwise this function is forbidden.

Procedures: Connect all instruments as shown in figure 33, enter target gas calibration interface, release



standard gas slowly and control gas flow within 600ml/min,observe the real-time concentration value (concentration value should be increasing),wait until real-time concentration value rise to the peak reading and stay still, user can chose a un-calibrate option to operate( $\sqrt{}$  stand for this level has been calibrated and  $\times$  stand for this level still need to be calibrate);first of all input a concentration value of standard gas then calibrate. Target gas concentration value will set up to be the standard gas concentration value after calibration.

Ъ	ion 2	
Sensor	Channel	
EX	1	Enter
HCL	2	Enter
CH2O	3	Enter
HCN	4	Enter
SO2	5	Enter
HBr	6	Enter



#### 7.2.6 Alarm setting

User can set the alarm limit and alarm mode in this menu, as shown in figures 28-29, there are two alarm value setting, which are high alarm and low alarm. When user set as the low alarm mode, it will trigger alarm when real-time concentration is lower than preset value , when user switch to high alarm mode, it will trigger alarm when real-time concentration is higher than preset value.

Alarm Setting		28
Sensor	Channel	
EX	1	Enter
HCL	2	Enter
CH2O	3	Enter
HCN	4	Enter
SO2	5	Enter
HBr	6	Enter

	Alarm Setting	29
Sensor : EX	Unit : %LEL	
Alarm 1 :	00001.00	
Alarm Type :	LowAlarm	
Alarm 2 :	00002.00	
Alarm Type :	HiAlarm	



**Procedures:** Enter alarm settings sub-menu, Move the cursor to "Enter", press "Ok" to select and press "Up" and "Down" to switch alarm mode, then press "Ok" to save your modification.

#### 7.2.7 Measure Mode

User can choose two measure mode:real time measure and fixed time measure as shown in figure 30. When detector is preset as "real-time measure" mode, it provides continuous monitoring and will shows real-time concentration of each channel in the display. And you can select the duration of each fixed time detection, the detect cycle times and the interval between the two fixed time measure as shown in figure 31.

Measure Mode 30	Measure Mode 31
Real Time Measure     Fixed Time Measure	<ul><li>Real Time Measure</li><li>Fixed Time Measure</li></ul>
	Time: 0030 Second Cycle: 0000 Interval: 0001 Second

#### 7.2.8 Store Setting

Manually save, automatically save are optional in this menu, it also allows user to set storage cycle under automatically storage mode. Users can set the storage interval(interval of two storage data) when preset as "Auto Store Mode". The maximum setting is 999 second and the minimum setting is 1 second.(figure 32)

	Print Setting	33
O Manual	Print Model	
Auto Pri	int mode	
Company :	WithName	
Count :	02	
Time :	01 Minute	



#### 7.2.9 Print Setting

Manually print automatically print are optional in this menu. It can print data via a micro printer(the micro printer is optional accessory). The report will print with company name,count,time and unit of time as shown in figure 33

#### 7.2.10 Time Setting

Time setting menu allow user to set date and time, this time is related to the time of the concentration values are being recorded. (Figure 34)

Time Setting 34	12	Default Setting	35
	Sensor	Channel	
	EX	1	Reset
System Time :	HCL	2	Reset
2017 - 06 - 24	CH2O	3	Reset
10 : 35 : 24	HCN	4	Reset
	SO2	5	Reset
	HBr	6	Reset

#### 7.2.11 Factory Setting

If user proceeded an wrong operation by accidentally or need to reset all parameters to factory setting, you can reset all parameter to factory setting. (Figure 35)

#### 8. Common Faults and Exclusions

Problem: Concentration value is not stably when detector place in air, reading is unstable
 Possible reasons: Electrochemical sensor might interfered with unrelated colorless and odorless gas
 Solutions: Place detector at pure gas environment to see whether the concentration value decreasing or not, if it is that the environment is clear but the concentration value remains high, you need to proceed zero calibration



◆ Problem: No response or weak response when detecting

#### **Possible reasons:**

1) Oxygen content value of gas is too low: <5%VOL.

2) Gas pressure is too high, the pump can't not afford it.

3) Expired sensor might cause the problem too.

**Solutions:** Make sure the oxygen content value of the gas is higher than 5%VOL when equip with Electrochemistry sensor, Catalytic combustion sensor or Semiconductor sensor. Detector working pressure is -30Kpa~100Kpa, User can proceed zero calibration if has standard gas. If oxygen content value, working pressure are eligible for detection but problems still remain, user should return detector to factory for maintenance.

◆ **Problem:** Concentration value is unstable when start detecting.

**Possible reasons:**Normally dude to gas oxygen content is too low or changing of gas concentration value. **Solutions:** Increase gas oxygen content value and make sure the gas flow speed is stable.

Problem: Weak pumping, or device make a unusual sound while pumping.
 Possible reasons: Gas inlet blocked due to too many dust and vapor inhaled.
 Solutions: Return to manufacturer to replace the pump, install a dust and vapor filter at the gas inlet.

• **Problem:** Unable to boot up instrument.

Possible reasons: Battery low or empty

**Solutions:** Try to start the instrument after fully charged the battery, if the problem still remain, user need to return the device to manufacturer.

• **Problem:** Unable to charge the instrument

Possible reasons: Adapter failure or wrong adapter(12VDC, 1A)

**Solutions:** Make sure output voltage of adapter is 12V, user need to change a adapter if the output voltage is not 12V, if the problem still remain after change a adapter, user need to return the instrument to manufacturer.



#### 9. History data export instructions

Please kindly contact with the sales for the export software and manual.

#### 10. After-sales Service

#### A. WARRANTY

1.We provide 12-Month warranty for the detector and 3-Month warranty for the accessories.

2. We have free calibration once a year during the entire product's service life. (freight is not included)

3. From the date of purchase, quality problem occurred under normal use during the warranty period, you

can enjoy free maintenance services. Note: required working conditions: Temperature : -30 $\sim$ 50°C relative

humidity:0-90%RH pressure:0-200Kpa air environment: no interference gas, no dust

#### **B. LIMITATION**

(Note: Warranty will not be provided in case of the following circumstances.)

- 1. Man-made damage
- 2. Damage caused by natural disasters
- 3. Exceeds the warranty period
- 4. Unauthorized disassembly and modification
- 5. Purchase through non-legal distribution channels

#### C. SERVICE GUARANTEE

1. Maintenance within the scope of warranty does not charge maintenance fees, replacement parts

costs.(freight is not included)

2. Maintenance without the scope of warranty does not charge maintenance fees, but replacement parts will be charged at a discounted price.

3. All the complaints will be responded within 24 hours.

4. Address: 2nd floor, Innovation Building, Qixing Creative Industrial Park, Baotian 1st Road, Xixiang

Town, Bao'an District, Shenzhen City, Guangdong Province, China.



#### 11. Common gas type list

<b>—</b>			
02	0-1000,5000,10000,30000PPM; 0-5,25,30,100%VOL	H2S	0-50,100,500,1000,2000,5000,10000PPM
СО	0-100,500,1000,2000PPM	EX	0-2,4%VOL; 0-100%LEL
NH3	0-50,100,500,1000,5000PPM	CO2	0-2000,5000,10000,50000PPM; 0-10,20 %,50%,100%VOL
SO2	0-1,10,20,50,100,500,1000,2000PP M	CH2O	0-10,20,50,100PPM
VOC	0-10,20,50,100,200,500,1000,2000, 5000PPM	03	0-1,2,5,10,20,50,100,500,1000,2000,5000 PPM
NO	0-1,2,5,50,100,250,500,1000,2000, 5000PPM	NO2	0-1,20,50,100,500,1000,2000PPM
CLO2	0-1,5,10,20,50PPM	H2	0-500,1000,5000,20000,40000PPM; 0-100%VOL
N2	0-100%VOL	CS2	0-50,100,500PPM
CH4	0-5000,10000,50000PPM; 0-20%, 50%,100%VOL	C2H2	0-100,500,1000,2000PPM; 0-2%VOL; 0-100%LEL
C2H4	0-10,50,100,200,500,1000,2000PP M	С2Н6	0-5000,10000,30000PPM
СЗН8	0-5000,10000,20000PPM; 0-20%, 50%,100%VOL	C4H10	0-5000,10000,20000PPM
HF	0-10,20,50PPM	PH3	0-5,20,50,100,500,1000,2000,4000PPM
HCN	0-30,50,100,500,1000PPM	HCL	0-10,20,50,100,200,500,1000,3000PPM
CL2	0-10,20,50,100,200,500,1000,2000, 5000PPM	CH3Br	0-1,6,100%VOL; 0-200g/m3; 0-5000,10000,30000PPM
Ar	0-100%VOL	He	0-100%VOL
SF6	0-500,1000,2000PPM	ETO	0-10,20,50,100,500PPM; 0-3%VOL





ADD: 2nd Floor, Innovation Building, Qixing Creative Industrial Park, Baotian 1st

Road, Xixiang Town, Bao an District, Shenzhen City, Guangdong Province, China

TEL: +86 0755 86110165-211

VIP HOTLINE: +86 15014056865 Ms Mark

FAX: +86 0755 27225732

EMAIL: sales05@szkorno.com

Web Site: <u>http://www.gdszken.com/</u>

To get more information please visit our website or contact our engineer